



Mark one end of two each pcs of 1" emt with any paint or marker. These ends will be the bottom of the gothic hoop. Began bending 1" emt by sliding 24" inches of the marked end of the tube through the holding strap of the C-12 bender. Proceed with bending, making sure each bending stroke stops before reaching end of the bender, and insuring that the tubing remains level with the bender on the output side of the bender... For the last bending stroke insert special lever bar and bend until junction of lever bar/emt contact the bender body. Remove tubing, repeat steps on second emt tube. **Note, too reduce the base width began the bending process at a value less than 24 inches.. Too widen the base width began bending at a value more than 24 inches**



